

Lumbar Support Move the lumbar support up or down to desired position. Arm Height Adjustment To adjust the arm height, push on the button on the outside of the arm. **Tension Control** Provides a firmer or softer recline adjustment. Turn hand wheel on the front of the mechanism: clockwise for more tension, counterclockwise for less tension.

Pneumatic Lift

Easily adjusts to the perfect seat height. To raise the seat, lift your weight off the seat and twist up towards the back of the paddle. Release lever when seat reaches desired height. To lower seat, twist up towards the back of the paddle while you are seated; release lever when seat reaches desired height.

Seat Depth Adjustment

Lift lever and slide seat forward or back. Release lever to lock.

